

User Manual

# GETTING STARTED? EASY.



ZOB142W  
ZOB142X

EN User Manual  
Oven

# ZANUSSI

## VISIT OUR WEBSITE TO:

---



Get usage advice, brochures, trouble shooter, service and repair information:  
[www.zanussi.com/support](http://www.zanussi.com/support)

## SAFETY INFORMATION

---

Before the installation and use of the appliance, carefully read the supplied instructions. The manufacturer is not responsible for any injuries or damage that are the result of incorrect installation or usage. Always keep the instructions in a safe and accessible location for future reference.

## **CHILDREN AND VULNERABLE PEOPLE SAFETY**

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children of less than 8 years of age and persons with very extensive and complex disabilities shall be kept away from the appliance unless continuously supervised.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep all packaging away from children and dispose of it appropriately.
- **WARNING:** Keep children and pets away from the appliance when it operates or when it cools down. Accessible parts become hot during use.
- If the appliance has a child safety device, it should be activated.
- Children shall not carry out cleaning and user maintenance of the appliance without supervision.

## **GENERAL SAFETY**

- Only a qualified person must install this appliance and replace the cable.
- Do not use the appliance before installing it in the built-in structure.

- Disconnect the appliance from the power supply before carrying out any maintenance.
- If the mains power supply cable is damaged, it must be replaced by the manufacturer, its Authorised Service Centre or similarly qualified persons to avoid an electrical hazard.
- The means for disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.
- **WARNING:** Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock.
- **WARNING:** The appliance and its accessible parts become hot during use. Care should be taken to avoid touching heating elements.
- Always use oven gloves to remove or put in accessories or ovenware.
- Do not use a steam cleaner to clean the appliance.
- Do not use harsh abrasive cleaners or sharp metal scrapers to clean the glass door since they can scratch the surface, which may result in shattering of the glass.

## SAFETY INSTRUCTIONS

### INSTALLATION



**WARNING!** Only a qualified person must install this appliance.

- Remove all the packaging.
- Do not install or use a damaged appliance.
- Follow the installation instructions supplied with the appliance.
- Always take care when moving the appliance as it is heavy. Always use safety gloves and enclosed footwear.
- Do not pull the appliance by the handle.
- Install the appliance in a safe and suitable place that meets installation requirements.
- Keep the minimum distance from other appliances and units.
- Before mounting the appliance, check if the oven door opens without restraint.
- The appliance is equipped with an electric cooling system. It must be operated with the electric power supply.

|   |              |
|---|--------------|
| Cabinet minimum height (Cabinet under the worktop minimum height) | 580 (600) mm |
| Cabinet width   | 560 mm       |
| Cabinet depth   | 550 (550) mm |
| Height of the front of the appliance                              | 589 mm       |
| Height of the back of the appliance                               | 570 mm       |
| Width of the front of the appliance                               | 594 mm       |
| Width of the back of the appliance                                | 558 mm       |
| Depth of the appliance  | 561 mm       |
| Built in depth of the appliance                                   | 540 mm       |
| Depth with open door  | 1007 mm      |

|  |           |
|--|-----------|
| Ventilation opening minimum size. Opening placed on the bottom rear side | 560x20 mm |
| Mounting screws  | 4x25 mm   |

## ELECTRICAL CONNECTION



**WARNING!** Risk of fire and electric shock.

- All electrical connections should be made by a qualified electrician.
- The appliance must be earthed.
- Make sure that the parameters on the rating plate are compatible with the electrical ratings of the mains power supply.
- Always use a correctly installed shockproof socket.
- Do not use multi-plug adapters and extension cables.
- Make sure not to cause damage to the mains plug and to the mains cable. Should the mains cable need to be replaced, this must be carried out by our Authorised Service Centre.
- Do not let mains cables touch or come near the appliance door or the niche below the appliance, especially when it operates or the door is hot.
- The shock protection of live and insulated parts must be fastened in such a way that it cannot be removed without tools.
- Connect the mains plug to the mains socket only at the end of the installation. Make sure that there is access to the mains plug after the installation.
- If the mains socket is loose, do not connect the mains plug.
- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug.
- Use only correct isolation devices: line protecting cut-outs, fuses (screw type fuses removed from the holder), earth leakage trips and contactors.
- The electrical installation must have an isolation device which lets you disconnect the appliance from the mains at all poles. The isolation device must have a contact opening width of minimum 3 mm.
- This appliance is supplied without a main plug and a main cable.

## Cable types applicable for installation or replacement for Europe:

H07 RN-F, H05 RN-F, H05 RRF, H05 VV-F, H05 V2V2-F (T90), H05 BB-F

For the section of the cable refer to the total power on the rating plate. You can also refer to the table:

| Total power (W) | Section of the cable (mm <sup>2</sup> ) |
|-----------------|---|
| maximum 1380    | 3 x 0.75                                |
| maximum 2300    | 3 x 1                                   |
| maximum 3680    | 3 x 1.5                                 |

The earth cord (green / yellow cable) must be 2 cm longer than phase and neutral cables (blue and brown cables).



## USE



**WARNING!** Risk of injury, burns and electric shock or explosion.

- This appliance is for household (indoors) use only.
- Do not change the specification of this appliance.
- Make sure that the ventilation openings are not blocked.
- Do not let the appliance stay unattended during operation.
- Deactivate the appliance after each use.
- Be careful when you open the appliance door while the appliance is in operation. Hot air can release.
- Do not operate the appliance with wet hands or when it has contact with water.
- Do not apply pressure on the open door.
- Do not use the appliance as a work surface or as a storage surface.
- Open the appliance door carefully. The use of ingredients with alcohol can cause a mixture of alcohol and air.
- Do not let sparks or open flames to come in contact with the appliance when you open the door.

- Do not put flammable products or items that are wet with flammable products in, near or on the appliance.



**WARNING!** Risk of damage to the appliance.

- To prevent damage or discoloration to the enamel:
  - do not put ovenware or other objects in the appliance directly on the bottom.
  - do not put aluminium foil directly on the bottom of cavity of the appliance.
  - do not put water directly into the hot appliance.
  - do not keep moist dishes and food in the appliance after you finish the cooking.
  - be careful when you remove or install the accessories.
- Discoloration of the enamel or stainless steel has no effect on the performance of the appliance.
- This appliance is for cooking purposes only. It must not be used for other purposes, for example room heating.
- Always cook with the oven door closed.
- If the appliance is installed behind a furniture panel (e.g. a door) make sure the door is never closed when the appliance operates. Heat and moisture can build up behind a closed furniture panel and cause subsequent damage to the appliance, the housing unit or the floor. Do not close the furniture panel until the appliance has cooled down completely after use.

## CARE AND CLEANING



**WARNING!** Risk of injury, fire, or damage to the appliance.

- Before maintenance, deactivate the appliance and disconnect the mains plug from the mains socket.
- Make sure the appliance is cold. There is the risk that the glass panels can break.
- Replace immediately the door glass panels when they are damaged. Contact the Authorised Service Centre.

- Be careful when you remove the door from the appliance. The door is heavy!
- Clean regularly the appliance to prevent the deterioration of the surface material.
- Clean the appliance with a moist soft cloth. Use only neutral detergents. Do not use abrasive products, abrasive cleaning pads, solvents or metal objects.
- If you use an oven spray, follow the safety instructions on its packaging.

## INTERNAL LIGHTING



**WARNING!** Risk of electric shock.

- Concerning the lamp(s) inside this product and spare part lamps sold separately: These lamps are intended to withstand extreme physical conditions in household appliances, such as temperature, vibration, humidity, or are intended to signal information about the operational status of the appliance. They are not intended to be used in other applications and are not suitable for household room illumination.
- This product contains a light source of energy efficiency class G.
- Use only lamps with the same specifications.

## SERVICE

- To repair the appliance contact the Authorised Service Centre.
- Use original spare parts only.

## DISPOSAL



**WARNING!** Risk of injury or suffocation.



- Contact your municipal authority for information on how to dispose of the appliance.
- Disconnect the appliance from the mains supply.
- Cut off the mains electrical cable close to the appliance and dispose of it.
- Remove the door catch to prevent children or pets from becoming trapped in the appliance.

# INSTALLATION


## BUILDING IN



**WARNING!** Refer to Safety chapters.




## SECURING THE OVEN TO THE CABINET



# PRODUCT DESCRIPTION

## GENERAL OVERVIEW



- 1 Control panel
- 2 Knob for the heating functions
- 3 Control knob (for the temperature)
- 4 Temperature indicator / symbol
- 5 Air vents for the cooling fan
- 6 Heating element
- 7 Lamp
- 8 Fan
- 9 Shelf positions

## ACCESSORIES

- **Wire shelf**  
For cookware, cake tins, roasts.
- **Grill- / Roasting pan**  
To bake and roast or as pan to collect fat.
- **Trivet**

For roasting and grilling.



Use the trivet only with the Grill- / roasting pan.

## BEFORE FIRST USE



**WARNING!** Refer to Safety chapters.

### BEFORE FIRST USE

The oven can emit an odour and smoke during preheating. Make sure that the room is ventilated.



#### Step 1

#### Clean the oven

1. Remove all accessories from the oven.
2. Clean the oven and the accessories with a soft cloth, warm water and a mild detergent.



#### Step 2

#### Preheat the empty oven

1. Set the maximum temperature for the function: .  
Time: 1 h.
2. Set the maximum temperature for the function: .  
Time: 15 min.

Turn off the oven and wait until it is cold. Place the accessories in the oven.

# DAILY USE



**WARNING!** Refer to Safety chapters.

## HOW TO SET: HEATING FUNCTION

|               |   |
|---------------|---|
| <b>Step 1</b> | Turn the knob for the heating functions to select a heating function.           |
| <b>Step 2</b> | Turn the control knob to select the temperature.                                |
| <b>Step 3</b> | When the cooking ends, turn the knobs to the off position to turn off the oven. |

## HEATING FUNCTIONS

| Heating function     | Application  |
|----------------------|--|
| <br>Off position     | The oven is off.   |
| <br>Light            | To turn on the lamp.   |
| <br>True Fan Cooking | To bake on up to two shelf positions at the same time and to dry food.   |
| <br>Moist Fan Baking | This function is designed to save energy during cooking. When you use this function, the temperature in the cavity may differ from the set temperature. The heating power may be reduced. For more information refer to "Daily Use" chapter, Notes on: Moist Fan Baking. |

| Heating function | Application  |
|------------------|--|
| <br>Defrost      | To defrost food (vegetables and fruit). The defrosting time depends on the amount and size of the frozen food. |
| <br>Grill        | To grill thin pieces of food and to toast bread.   |

## NOTES ON: MOIST FAN BAKING

This function was used to comply with the energy efficiency class and ecodesign requirements. Tests according to BS EN 60350-1.

The oven door should be closed during cooking so that the function is not interrupted and the oven operates with the highest energy efficiency possible.

For the cooking instructions refer to "Hints and tips" chapter, Moist Fan Baking. For general energy saving recommendations refer to "Energy Efficiency" chapter, Energy Saving.



# USING THE ACCESSORIES




**WARNING!** Refer to Safety chapters.

## INSERTING ACCESSORIES


### Wire shelf:

Push the shelf between the guide bars of the shelf support and make sure that the feet point down.



### Deep pan:

Push the tray between the guide bars of the shelf support.




## TRIVET AND GRILL- / ROASTING PAN

**Step 1** Put the trivet into a deep pan.

**Step 2** Put the deep pan on the recommended shelf position.


### Roasting larger pieces of meat or poultry on one shelf position.

Make sure the supports of the wire shelf point up.



### Grilling and toasting thin pieces of food in large quantities.

Make sure the supports of the wire shelf point down.



# ADDITIONAL FUNCTIONS

## COOLING FAN

When the oven operates, the cooling fan turns on automatically to keep the surfaces of the oven cool. If you turn off the oven, the cooling fan stops.

prevent this, the oven has a safety thermostat which interrupts the power supply. The oven turns on again automatically when the temperature drops.

## SAFETY THERMOSTAT

Incorrect operation of the oven or defective components can cause dangerous overheating. To

# HINTS AND TIPS



Refer to Safety chapters.

## COOKING RECOMMENDATIONS

The oven has four shelf positions.

Count the shelf positions from the bottom of the oven floor.

Your oven may bake or roast differently to the oven you had before.

### Baking cakes

Do not open the oven door before 3/4 of the set cooking time is up.

If you use two baking trays at the same time, keep one empty level between them.

### Cooking meat and fish

Use a deep pan for very fatty food to prevent the oven from stains that can be permanent.

Leave the meat for approximately 15 minutes before carving so that the juice does not seep out.

To prevent too much smoke in the oven during roasting, add some water into the deep pan. To prevent the smoke condensation, add water each time after it dries up.





### Cooking times

Cooking times depend on the type of food, its consistency, and volume.

Initially, monitor the performance when you cook. Find the best settings (heat setting, cooking time, etc.) for your cookware, recipes and quantities when you use this appliance.






## MOIST FAN BAKING - RECOMMENDED ACCESSORIES






Use the dark and non-reflective tins and containers. They have better heat absorption than the light colour and reflective dishes.

|  |   |  |  |
|--|---|--|--|
|  <p><b>Pizza pan</b></p> |  <p><b>Baking dish</b></p> |  <p><b>Ramekins</b></p> |  <p><b>Flan base tin</b></p> |
| <p>Dark, non-reflective<br/>28 cm diameter</p>   | <p>Dark, non-reflective<br/>26 cm diameter</p>  | <p>Ceramic<br/>8 cm diameter,<br/>5 cm height</p>  | <p>Dark, non-reflective<br/>28 cm diameter</p>   |

## MOIST FAN BAKING








For the best results follow suggestions listed in the table below.

|  |  | <br>(°C) |  | <br>(min) |
|---|---|---|---|--|
| Sweet rolls, 12 pieces  | baking tray or dripping pan   | 180   | 2   | 35 - 40  |
| Rolls, 9 pieces   | baking tray or dripping pan   | 180   | 2   | 35 - 40  |
| Pizza, frozen, 0.35 kg  | wire shelf  | 220   | 2   | 35 - 40  |
| Swiss roll  | baking tray or dripping pan   | 170   | 2   | 30 - 40  |
| Brownie   | baking tray or dripping pan   | 180   | 2   | 30 - 40  |
| Soufflé, 6 pieces   | ceramic ramekins on wire shelf  | 200   | 3   | 30 - 40  |
| Sponge flan base  | flan base tin on wire shelf   | 170   | 2   | 20 - 30  |
| Victoria sandwich   | baking dish on wire shelf   | 170   | 2   | 35 - 45  |
| Poached fish, 0.3 kg  | baking tray or dripping pan   | 180   | 3   | 35 - 45  |
| Whole fish, 0.2 kg  | baking tray or dripping pan   | 180   | 3   | 35 - 45  |
| Fish fillet, 0.3 kg   | pizza pan on wire shelf   | 180   | 3   | 35 - 45  |
| Poached meat, 0.25 kg   | baking tray or dripping pan   | 200   | 3   | 40 - 50  |
| Shashlik, 0.5 kg  | baking tray or dripping pan   | 200   | 3   | 25 - 35  |
| Cookies, 16 pieces  | baking tray or dripping pan   | 180   | 2   | 20 - 30  |
| Macaroons, 20 pieces  | baking tray or dripping pan   | 180   | 2   | 40 - 45  |
| Muffins, 12 pieces  | baking tray or dripping pan   | 170   | 2   | 30 - 40  |
| Savory pastry, 16 pieces  | baking tray or dripping pan   | 170   | 2   | 35 - 45  |
| Short crust biscuits, 20 pieces   | baking tray or dripping pan   | 150   | 2   | 40 - 50  |
| Tartlets, 8 pieces  | baking tray or dripping pan   | 170   | 2   | 20 - 30  |
| Vegetables, poached, 0.4 kg   | baking tray or dripping pan   | 180   | 3   | 35 - 40  |

|  |  | <br>(°C) |  | <br>(min) |
|---|---|---|---|--|
| Vegetarian omelette   | pizza pan on wire shelf   | 200   | 3   | 30 - 45  |
| Mediterranean vegetables, 0.7 kg  | baking tray or dripping pan   | 180   | 4   | 35 - 40  |

### INFORMATION FOR TEST INSTITUTES

Tests according to IEC 60350-1.

|  |  |  |  | <br>(°C) | <br>(min) |    |
|---|---|---|---|---|--|---|
| Toast, 4 - 6 pieces   | Grill   | Wire shelf  | 3   | max.  | 2 - 4 minutes first side; 2 - 3 minutes second side  | Preheat the oven for 3 minutes.   |
| Beef burger, 6 pieces, 0.6 kg   | Grill   | Wire shelf and dripping pan   | 3   | max.  | 20 - 30  | Put the wire shelf on the third level and the dripping pan on the second level of the oven. Turn the food halfway through the cooking time. Preheat the oven for 3 minutes. |

## CARE AND CLEANING



**WARNING!** Refer to Safety chapters.

### NOTES ON CLEANING



**Cleaning Agents**

Clean the front of the oven with a soft cloth with warm water and a mild detergent. Clean and check the door gasket around the frame of the cavity.

Use a cleaning solution to clean metal surfaces.

Clean stains with a mild detergent.



### Everyday Use

Clean the cavity after each use. Fat accumulation or other residue may cause fire.

Moisture can condense in the oven or on the door glass panels. To decrease the condensation, let the oven work for 10 minutes before cooking. Do not store the food in the oven for longer than 20 minutes. Dry the cavity with a soft cloth after each use.



### Accessories

Clean all accessories after each use and let them dry. Use a soft cloth with warm water and a mild detergent. Do not clean the accessories in a dishwasher.





Do not clean the non-stick accessories using abrasive cleaner or sharp-edged objects.



## HOW TO REMOVE AND INSTALL: DOOR

The oven door has two glass panels. You can remove the oven door and the internal glass panel to clean it. Read the whole "Removing and installing door" instruction before you remove the glass panels.



**CAUTION!** Do not use the oven without the glass panels.


|   |  |  |   |
|---|--|--|---|
| <b>Step 1</b>   | Open the door fully and hold both hinges.  | <b>Step 2</b>  | Lift and turn the levers fully on both hinges.  |
|    |  |    |   |
| <b>Step 3</b>   | Close the oven door halfway to the first opening position. Then lift and pull forward and remove the door from its seat. | <b>Step 4</b>  | Put the door on a soft cloth on a stable surface and release the locking system to remove the internal glass panel. |
|  |  |  |   |
| <b>Step 5</b>   | Turn the fasteners by 90° and remove them from their seats.  | <b>Step 6</b>  | First lift carefully and then remove the glass panel.   |



**Step 7** Clean the glass panels with water and soap. Dry the glass panels carefully. Do not clean the glass panels in the dishwasher.

**Step 8** After cleaning, install the glass panel and the oven door.

When installed correctly the door trim clicks. Make sure that you install the internal glass panel in the seats correctly.



## HOW TO REPLACE: LAMP



**WARNING!** Risk of electric shock.  
The lamp can be hot.

### Before you replace the lamp:

| Step 1  | Step 2                              | Step 3                                   |
|---|-------------------------------------|--|
| Turn off the oven. Wait until the oven is cold. | Disconnect the oven from the mains. | Put a cloth on the bottom of the cavity. |

### Back lamp

|               |  |
|---------------|--|
| <b>Step 1</b> | Turn the glass cover to remove it.                           |
| <b>Step 2</b> | Clean the glass cover.                                       |
| <b>Step 3</b> | Replace the lamp with a suitable 300 °C heat-resistant lamp. |
| <b>Step 4</b> | Install the glass cover.                                     |

## TROUBLESHOOTING



**WARNING!** Refer to Safety chapters.

### WHAT TO DO IF...

In any cases not included in this table please contact with an Authorised Service Centre.

| Problem                    | Check if...        |
|----------------------------|--------------------|
| The oven does not heat up. | The fuse is blown. |

| Problem                     | Check if...  |
|-----------------------------|--|
| The door gasket is damaged. | Do not use the oven. Contact an Authorised Service Centre. |

| Problem                 | Check if...            |
|-------------------------|------------------------|
| The lamp does not work. | The lamp is burnt out. |

## SERVICE DATA

If you cannot find a solution to the problem yourself, contact your dealer or an Authorised Service Centre. The necessary data for the service centre is on the rating plate. The rating plate is on the front frame of the oven cavity. Do not remove the rating plate from the oven cavity.

**We recommend that you write the data here:**

|                      |       |
|----------------------|-------|
| Model (MOD.)         | ..... |
| Product number (PNC) | ..... |
| Serial number (S.N.) | ..... |

## ENERGY EFFICIENCY

### PRODUCT INFORMATION SHEET ACCORDING TO UK ECODESIGN AND ENERGY LABELLING REGULATIONS

|  |  |         |
|--|--|---------|
| Supplier's name  | Zanussi                                |         |
| Model identification                                     | ZOB142W 944064890<br>ZOB142X 944064889 |         |
| Energy Efficiency Index                                  | 94.8                                   |         |
| Energy efficiency class                                  | A                                      |         |
| Energy consumption with a standard load, fan-forced mode | 0.73 kWh/cycle                         |         |
| Number of cavities                                       | 1                                      |         |
| Heat source  | Electricity                            |         |
| Volume   | 53 l                                   |         |
| Type of oven   | Built-In Oven                          |         |
| Mass   | ZOB142W                                | 29.0 kg |
|  | ZOB142X                                | 29.0 kg |

BS EN 60350-1 - Household electric cooking appliances - Part 1: Ranges, ovens, steam ovens and grills - Methods for measuring performance.

## ENERGY SAVING



The oven has features which help you save energy during everyday cooking.

Make sure that the oven door is closed when the oven operates. Do not open the oven door too often during cooking. Keep the door gasket clean and make sure it is well fixed in its position. Use metal cookware to improve energy saving.

When possible, do not preheat the oven before cooking.

Keep breaks between baking as short as possible when you prepare a few dishes at one time.

### **Cooking with fan**

When possible, use the cooking functions with fan to save energy.

### **Residual heat**

When the cooking duration is longer than 30 min, reduce the oven temperature to minimum 3 - 10

min before the end of cooking. The residual heat inside the oven will continue to cook.

Use the residual heat to warm up other dishes.

### **Keep food warm**


Choose the lowest possible temperature setting to use residual heat and keep a meal warm.


### **Moist Fan Baking**

Function designed to save energy during cooking.

## **ENVIRONMENTAL CONCERNS**

---

Recycle materials with the symbol . Put the packaging in relevant containers to recycle it. Help protect the environment and human health by recycling waste of electrical and electronic appliances. Do not dispose of appliances marked

with the symbol  with the household waste. Return the product to your local recycling facility or contact your municipal office.









[WWW.ZANUSSI.COM/SHOP](http://WWW.ZANUSSI.COM/SHOP)



UK  
CA

867368786-A-322021